



## IMMOBILIZER SYSTEM PIAGGIO/VESPA

 <b>PIAGGIO</b>	Read Key ID in ECU	Reset, Erase all key	 <b>Vespa</b>	Read Key ID in ECU	Reset, Erase all key
BEVERLY 125 MIUG3	✓	✓	VESPA 125/150 3V MIUG3	✓	✓
BEVERLY 300 MIUG3	✓	✓	GTS 125/150 MIUG3	✓	✓
BEVERLY 350 MIUG3	✓	✓	LXV 125 3V MIUG3	✓	✓
FLY 125 MIUG3	✓	✓	GTS 125/300 ABS MIUG3	✓	✓
FLY 150 MIUG3	✓	✓	LT125/150 3V MIUG3	✓	✓
FLY 125 3V MIUG3	✓	✓	LX125 MIUG3	✓	✓
FLY 150 3V MIUG3	✓	✓	LX 125 AC19I/AC20I	✓	
FLY 125 AC19I/20I	✓		LX 125 AC19I/AC20I	✓	
FLY 150 AC 19I/20I	✓		LX 125 ACII/AC2I/AC5I	✓	
FLY 125 AC 19I/20I	✓		LX 125/150 E1MIUG3	✓	✓
FLY 150 AC 19I/20I	✓		LX 150 3V MIUG3	✓	✓
FLY AC III/AC2I/	✓		LX 150 AC19I/AC20I	✓	
AC5I/AC8I	✓		LX 150 AC19I/AC20I	✓	
LIBERTY 125 3V PGN04/PGS02 /PGT01	✓		LX 150 ACII/AC2I/AC5I	✓	
LIBERTY 150 3V MIUG3	✓	✓	LX 125/150 3V PGN04/PGS02/PGT01	✓	
LIBERTY 150 3V PGN04/PGS02 /PGT01	✓		LXV 125/150 2V/3V MIUG3	✓	✓
LIBERTY 125 AC19I/20I	✓		PRIMAVERA 125/150 MIUG3	✓	✓
LIBERTY 150 AC19I/20I	✓		PRIMAVERA 125 150/PGN04/PGS02/PGT01	✓	
LIBERTY 125 AC19I/20I	✓		PRIMAVERA ABS	✓	
LIBERTY 150 AC19I/20I	✓		S125/150 MIUG3	✓	✓
LIBERTY AC III/AC2I/AC5I/AC8I	✓		S125/150 3V MIUG3	✓	✓
LIBERTY ABS PGS06	✓		SPRINT 125 3V PGN04	✓	
MEDLEY 125/ PGQ16	Updating	Updating	SPRINT 150 3V PGN04	✓	
MEDLEY 150 PGQ16	Updating	Updating	SPRINT ABS	✓	